Credit Card Type Special Event Countdown Clock
ModelNo.: CD200

Type A.

Fridge Magnet
(50 x 1.5 mm if needed)

55.6

90.6

6

Type B.

3 Keys (membrane)

SET — To select the digit to be set. The selected digit becomes blinking.
　　　　 Place at the backside under the battery cover to avoid touched in accident.
▲/MODE — To change dispaly mode, and to adjust reading upward.
▼/:00 — To adjust reading downward, and calibration of second.

scale: mm
By VOSCA 4/19/2011