Credit Card Type Special Event Countdown Clock

Model No.: CD200A
Type A. 3 Keys on Front

Fridge Magnet
(50 x 1.5 mm if needed)

88:88

TARGET   DAYS

SET

▼ :00

▲ MODE

Your Logo

55.6

90.6

6

3 Keys (membrane)

SET   – To select the digit to be set. The selected digit becomes blinking.

▲/MODE – To change dispaly mode, and to adjust reading upward.

▼/:00   – To adjust reading downward, and calibration of second.

Model No.: CD200B
Type B (Set Key at Backside)

88:88

TARGET   DAYS

Your Logo

▲ MODE

2 Keys

1) SET – To select the digit to be set. The selected digit becomes blinking.
    Placed at the backside under the battery cover to avoid touched by accident.

2) ▲/MODE – To change dispaly mode, and to adjust reading upward.

scale: mm
By VOSCA 11/24/2011