

Data Sheet


Model No.: 4XC-A0J, 4XE-A0J Regular Clock Module

Main Features

1. 12-Hr or 24 Hr version
2. Display screen size: 35 x 15.5 mm
3. Key: 2; set, and adjust
4. Power: 1.5 VDC,

Pin Definition

1. VDD/1.5V: +1.5V, short to each key to activate
2. GND: Ground
3. SET: Key to enter setting of hour and minute
4. ADJ: Key to adjust



scale: mm

How to Set Realtime

1. Connect power supply, 1.5V (VDD) and GND
2. LCD screen full displayed for 10 seconds then displays 12:00, or 0:00.
3. Short VDD to "SET" once to enter hour setting. The left-hand two digits blinking.
4. Repeat short VDD to "ADJ" to advance the hour
5. Short VDD to "SET" once again to enter minute setting. The right-hand two digits blinking.
6. Repeat short VDD to "ADJ" to advance minute.
7. To complete the setting and return to realtime, short VDD to "SET" once again, or just wait for 10 sec.

revised on 8/19/2021