




50D-1A0-0N-MS

CLOCK MODE (default)



TIMER MODE



A. The Keys

- a) CLOCK - press to enter clock mode from timer mode.
- b) SET - Press to enter each setting mode of real time.
- c) UP - Press to adjust hour or minute.
- d) TIMER/START/STOP - press to enter timer mode from clock mode. At timer mode, press to start or stop countdown timer.
- e) MIN - to adjust minute
- f) SEC - to adjust second

B. How to Set Real Time

Full screen is displayed for 3 seconds when power on, then return to 0:00.
Press "SET" key to enter setting mode of hour. The "HOUR" will be blanking. Use "UP" key to adjust hour. Press "SET" key again to enter setting mode of minute. The "MINUTE" will be blanking. Use "UP" key again to adjust minute. Press "SET" key again to return to normal display.

C. How to Set Countdown Timer

At real time mode, press d key to enter timer mode. Use e, and f keys to adjust the time period you are going to set countdown. Press d key to start countdown. Press d key again to stop timer.

D. How to Reset the Setting of Countdown Timer

Press e, and f keys together at the same time to reset the reading.